


One BZ-200 Power Pack and Sensor(s)



* At least 3 Sensors
can be powered by the
power pack.
See Sensor data sheet.

** BZ-200 Power Pack
must be grounded to
ensure signal integrity,
not for safety ground.

Watt Stopper/Legrand 800-879-8585			
Title One BZ-200 Power Pack and Sensor(s)			
Scale	Drawing#	Date	Rev.
None	57-003-7	08/06/15	0